

To clean the oven burner orifice, follow the following instructions:

1. Unscrew the oven burner bracket from the back of the stove.
2. Rotate the burner 180 degrees to gain access to the orifice.
3. Remove the orifice from the orifice holder with a 7mm wrench (#56 is the orifice and # 57 is the holder)
4. Clean out the orifice with forced air or with a cotton swab dipped in Alcohol.

Never use metal to clean the orifice

